



INSTALLATION INSTRUCTIONS

Part Number E-1023

This filter fits:

Please see current K&N catalog for complete listing

***FREE K&N DECAL To register your warranty, please see us online at knfilters.com/register. FREE K&N DECAL ***

Congratulations, you have purchased the finest air filter that money can buy. With proper care, this filter will last 1 million miles or more. This filter is a direct replacement for the stock air filter, and no modifications will be required. However the following procedure **MUST** be followed to ensure a proper fit and seal of the air filter.

- 1) Loosen the hose clamps on the main intake that connects the airbox to the engine.
- 2) Remove the bolts on the airbox lid.
- 3) Remove the airbox lid and pull out the stock filter.
- 4) Install the Pre-oiled K&N Filtercharger.

NOTE: 1982-92 Models:

Require the removal of rubber plug so that the filter can be mounted on the airbox lid with existing bolt/wingnut.

NOTE: 1993 Models:

Install filter then install airbox lid (before tightening airbox lid, reach hand through the center of the lid and check to see if filter is properly seated).

- 5) Tighten bolts on airbox lid.
- 6) Connect hose from engine to airbox lid.
- 7) Start engine and check for leaks

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THEENGINE COULD RESULT.