EFE POWER

INSTALLATION INSTRUCTIONS

MAKE: FORD MODEL: MUSTANG YEAR: 2015-2017 ENGINE: V8-5.0L Cat-Back Exhaust 304 Stainless Steel 49-33087-P (Polished Tips) 49-33087-B (Black Tips)

aFe recommends professional installation on our products. Caution: Allow time for your vehicle to cool down prior to installation. When working on or under your vehicle proceed with caution. Band Clamps 2-1/4" (x2) Exhaust systems reach high temperatures and may cause serious 05-41210 burns. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation. **Step 1:** Disconnect the battery from the vehicle. A **Step 2:** Securely support the vehicle on a lift or **Extension Pipes** on jack stands with at least 24 inches of 05-45914 clearance from the frame rail to the Band Clamps 3" (x7) around. 05-41055 **Step 3:** Loosen both driver and passenger side factory clamp sleeve located right before the factory exhaust resonator. S/A X-Pipe **Step 4:** Remove the Driver and Passenger side 05-145097 hanger brackets. **Step 5:** Remove the factory exhaust system. **Step 6:** Remove the factory exhaust hanger brackets and install them onto the aFe performance exhaust system. **Step 7:** Install the aFe reduced extension pipes to the factory exhaust converter pipes *aFe Power Badge using the provided clamps. (Note: If equipped with aFe Performance headers install the high flow 3" S/A Left H-Pipe extensions pipes for full exhaust 05-145091 performance and sound). Step 8: Install aFe X-pipe using provided clamps. Do not tighten at this time. S/A Right H-Pipe (Note: *Afe Power badge should be 05-145092 on the passenger side) **Step 9:** Connect the left and right muffler assemblys using provided clamps. Do not tighten at **Right Muffler Assembly** this time. 05-145094 Step 10: Install the combined left and right Left Muffler Assembly muffler assembly. - 05-145093 Step 11: Adjust exhaust before tightening. Step 12: Tighten all clamps. Step 13: Re-connect the battery. **Stainless Steel Tips** Step 14: Re-check all your work. Check system R49T30405-P06 (Polished) and re-tighten after 150 miles. R49T30405-B06 (Black) Thank you for choosing aFe Power!

Note: It is normal for your exhaust system to emit smoke for the first few minutes upon initial start-up due to grease used in the mandrel bending process.

⁰⁶⁻⁸⁶²⁷³ Updated: Oct, 2019